

FAST JACK CONNECTOR INSTRUCTIONS

1. TRIM CABLE END TO REMOVE BUMPS AND LOOSE ENDS.
2. LEAVE CABLE RELIEF IN CONNECTOR.
3. REMOVE THE SHORT SET SCREW FROM CONNECTOR AND LOOSEN THE OTHER.
4. INSERT CABLE TRIMMED END INTO CONNECTOR, PUSH UNTIL THE INNER WIRE IS SHOWING IN HOLE 'A'.
5. RE-INSERT SHORT SET SCREW WITH ALLEN WRENCH AND TIGHTEN.
6. INSERT THE LONG SET SCREW, TIGHTEN, DO NOT OVERTIGHTEN.
7. TEST CONNECTOR FOR SHORTS, REPEAT IF ANY ARE SHORTED.



